



## **SAFETY**

The safety of your child depends on these instructions.  
This is an activity toy with moving parts.  
Regular checks are essential, in order to prevent the toy from becoming a hazard.

## **MAINTENANCE**

Make deliberate and thorough checks at the beginning and throughout each season.

- Check Swing Seat's body, ropes (or chains) & clips and pay particular to the highest (moving) point of attachment for evidence of deterioration.
- Do not use the Swing Seat if there is evidence of deterioration. Contact TFH for replacements, which should be installed in accordance with instructions.

## **ACCESSORIES**

Changes to the Swing Seat must be carried out according to instructions from TFH.

